


Wheel trim information

Before you decide to buy wheel trims it's very important to determine the size of the wheel trims. Luckily this is quite easy. Vehicle selector or the number plate check on Winparts.co.uk are not decisive. In most cases the inch size can be found on your tyre.



How do I determine the inch size of my tyre?

The exact size of your rim is indicated on your tyre. The inch size can be found just after the letter 'R'. In the example above the inch size of the tyre is 15 inches.

You bought new wheel trims, what's next ?

Please consider the following steps for assembling the wheel trims you've just bought at Winparts:

1. Check if the size of the wheel trim match the size of the tyre.
2. Place the additional ring in the wheel trim with the recess in the direction of the valve stem. How to place the ring exactly differs per brand. On the packaging of the wheel trims you can find more information.
3. Place the wheel trim with the valve stem recess over the valve stem on the rims. Make sure that the valve stem is centred accordingly in the recess.
4. Push the wheel trim carefully on the wheel. In some cases extra force need to be applied. Further instructions can be found on the packaging.
5. Check if the wheel trim is mounted and secured correctly. It shouldn't get off easily, make sure it's fitted on correctly by fitting it on the edge of the rim.
6. Repeat steps 2 to 5 for assembling the other wheel trims.

